

Leg#1- Left side of dowr & Leg#2 - Right side of door

Braces: 2-80, 4-85 ½, 4-79, 2-71 &

- Bolt Platform in the Slots on Front of Blind; use 3/8 x 1" Bolt thru angle.
- · Raise blind
- Slide Leg into Stub, while holding leg put 1 ¼" Screws through Stubs into leg.
- Leave Blind 2" off Ground, Install Braces leaving all Bolts Loose.
- Lower Blind
- Pull Out on all Legs settling the Blind.
- Tighten All Bolts
- Install handrail

