

- Bolt Platform in the Slots on Front of Blind; use
 3 3/8 x 1" Bolt thru angle.
- Raise blind
- Slide Leg into Stub, while holding leg put 1 ¼"
 Screws through Stubs into leg.
- Leave Blind 2" off Ground, Install Braces leaving all Bolts Loose.
- Lower Blind
- Pull Out on all Legs settling the Blind.
- Tighten All Bolts
- Install handrail
- Raise Ladder and Fasten.
- Ø -- Marks 1" x 3/8" Bolts
- * -Marks Self Tapping Screws
- •

Tools Needed

- 9/16 Wrench
- 9/16 Socket and Ratchet
- 3/8 and 5/16 Hex Tips
- Cordless Drill